

# MUSEO BEEPER SEETINGS

## Corded & Cordless Devices

### Good Read Beep

Beeper **OFF**



Volume **LOW**



Volume **MEDIUM**



Volume **HIGH (Default)**



### Cordless Devices (Radio/Bluetooth)

#### Good Transmission Beep

Beep **ON (Default)**



Beep **OFF**



Volume **LOW**



Volume **MEDIUM**



Volume **HIGH (Default)**



#### Disconnect Beep

(Beep when scanner has become disconnected from base)

Beep **ON (Default)**



Beep **OFF**



#### Base Station Beep

(Beep when scanner is placed in the base)

Beep **ON (Default)**



Beep **OFF**

