

## Terminator Selection for Museo Devices

This settings are valid for RS-232, USB-Com & USB-KBD (Keyboard) interface type

Please enable your interface first!

DISABLE



[CR] / ENTER (DEFAULT MUSEO DEVICES)



[CRLF] / ENTER ENTER (DEFAULT ORIGINAL DL DEVICES)



[HT] / TAB

